

## ДИГИТАЛЕН ЧАСОВНИК С АЛАРМА ЕК-3885N

### Инструкция за употреба (на български)

Този модел ЕК-3885N е компактен цифров часовник с:

- час
- дата (месец / ден)
- ден от седмицата
- вътрешна температура
- аларма

#### □ **Настройване на часа**

1. Натисни и задръж бутона **SET**, докато дисплеят започне да мига.
2. Първо ще мига **часът**.
3. С бутоните **UP / DOWN (▲ / ▼)** настрой часа.
4. Натисни **SET**, за да преминеш към минутите.
5. Настрой минутите с **UP / DOWN**.
6. Натисни **SET**, за да запаметиш.

#### 📅 **Настройване на датата**

1. В режим **SET**, натискай **SET**, за да преминаваш през настройките.
2. Настрой по ред:
  - година (ако се поддържа)
  - месец
  - ден
3. Използвай **UP / DOWN**, за да променяш стойностите.
4. Потвърждавай с **SET**.

#### □ **Настройване на алармата**

1. Натисни бутона **ALARM**.
2. Задръж го, докато алармата започне да мига.
3. Настрой:
  - час (**UP / DOWN**)
  - минути (**UP / DOWN** или **SET** според версията)
4. Натисни **ALARM**, за да запаметиш.

✓ Когато е активна, на дисплея се появява символ **камбанка / AL**.

#### 🔔 **Включване / изключване на алармата**

- Натисни кратко бутона **ALARM**
- Символът за аларма се включва или изключва

## ⌘ Показване на температурата

- Показва се автоматично в °C
- Ако моделът поддържа:
  - задръж **DOWN**, за да смениш °C / °F

## ⌚ Формат 12 / 24 часа

- Натисни **UP** или **MODE**, за да смениш формата
- При някои версии: задръж **SET**

## ⚙ Превключване на режимите

Натискай **MODE**, за да превключваш:

- час → дата → температура → аларма

(при някои модели има и автоматично въртене)

## ⚡ Захранване

- Работи с USB адаптер (основно захранване)
- Батерия (ако има) запазва само настройките
- Дисплеят не работи само на батерия

## User Manual (English)

This EK-3885N is a compact LED digital alarm clock with:

- time display
- date (month / day)
- weekday
- indoor temperature
- alarm function

### □ Setting the Time

1. Press and hold the **SET** button until the display starts flashing.
2. The hour digits will flash first.
3. Use **UP / DOWN (▲ / ▼)** to adjust the hour.
4. Press **SET** to confirm and move to minutes.
5. Adjust minutes using **UP / DOWN**.
6. Press **SET** again to save the time.

### 📅 Setting the Date

1. In **SET mode**, press **SET** repeatedly to cycle through settings.
2. Adjust in order:
  - Year (if supported)
  - Month
  - Day
3. Use **UP / DOWN** to change values.
4. Press **SET** to confirm each step.

### □ Setting the Alarm

1. Press the **ALARM** button.
2. Hold it until the alarm time flashes.
3. Set:
  - Hour (UP / DOWN)
  - Minutes (UP / DOWN or SET depending on version)
4. Press **ALARM** to confirm.

✓ A **bell icon / “AL” indicator** appears when the alarm is active.

### 🔔 Turning Alarm ON / OFF

- Press **ALARM** briefly to toggle the alarm.
- The alarm icon will appear or disappear.

## ⌘ Temperature Display

- Shows automatically in °C.
- If supported:
  - Hold **DOWN** to switch between °C / °F.

## 🕒 12 / 24 Hour Format

- Press **UP** or **MODE** to switch format.
- On some versions, hold **SET** to change it.

## 🔄 Display Modes

Press **MODE** to cycle:

- Time → Date → Temperature → Alarm

(Some models may auto-cycle through these.)

## ⚡ Power Supply

- Works via USB adapter (main power).
- Backup battery (if present) only saves settings.
- Display does NOT run on battery alone.