

ДИГИТАЛЕН ЧАСОВНИК С АЛАРМА ЕК-5823L

Инструкция за употреба (на български)

Този модел ЕК-5823L е LED часовник с:

- час
- календар (месец / ден)
- ден от седмицата
- вътрешна температура
- аларма
- дистанционно управление (при някои версии)

□ **Настройване на часа**

1. Натисни и задръж бутона **SET / MODE**, докато дисплеят започне да мига.
2. Първо започва да мига **часът**.
3. С бутоните **UP / DOWN (▲ / ▼)** настрой часа.
4. Натисни **SET**, за да преминеш към минутите.
5. Настрой минутите с **UP / DOWN**.
6. Натисни отново **SET**, за да запаметиш.

Настройване на датата

1. В режим **SET** продължи да натискаш **SET**, за да преминаваш между настройките.
2. Настрой по ред:
 - година (ако се поддържа)
 - месец
 - ден
3. Използвай **UP / DOWN**, за да променяш стойностите.
4. Потвърждавай с **SET**.

□ **Настройване на алармата**

1. Натисни бутона **ALARM**.
2. Задръж го, докато алармата започне да мига.
3. Настрой:
 - час (**UP / DOWN**)
 - минути (**UP / DOWN** или **SET**)
4. Натисни **ALARM**, за да запаметиш.

✓ Когато е активна, се появява символ **камбанка / AL**.

Включване / изключване на алармата

- Натисни кратко бутона **ALARM**

- Символът на аларма се включва или изключва

⌘ Показване на температурата

- Показва се автоматично в °C
- Ако моделът поддържа:
 - задръж **DOWN**, за да смениш °C / °F

🕒 Формат 12 / 24 часа

- Натисни **UP** или **MODE**, за да смениш формата
- При някои версии: задръж **SET**

🔄 Превключване на режимите

Натискай **MODE**, за да сменяш:

- час → дата → температура → аларма

(при някои модели се върти автоматично)

🎮 Дистанционно управление (ако е включено)

- **MODE** – смяна на режимите
- **SET** – настройки
- **▲ / ▼** – промяна на стойности
- **ALARM** – аларма
- **LIGHT** – осветление / яркост

⚠ Захранване

- Работи с USB адаптер (основно захранване)
- Батерия (ако има) запазва само настройките
- Дисплеят не работи само на батерия

DIGITAL ALARM CLOCK EK-5823L

User Manual (English)

This EK-5823L model is an LED multifunction clock with:

- time display
- calendar (month / date)
- weekday
- indoor temperature
- alarm function
- remote control (on some versions)

□ Setting the Time

1. Press and hold the **SET / MODE** button until the display starts flashing.
2. The hour digits will flash first.
3. Use **UP / DOWN (▲ / ▼)** to adjust the hour.
4. Press **SET** to move to minutes.
5. Adjust minutes using **UP / DOWN**.
6. Press **SET** again to save the time.

Setting the Date

1. While in **SET mode**, press **SET** repeatedly to cycle through settings.
2. Adjust in order:
 - Year (if supported)
 - Month
 - Day
3. Use **UP / DOWN** to change values.
4. Press **SET** to confirm each step.

□ Setting the Alarm

1. Press the **ALARM** button.
2. Hold it until the alarm time starts flashing.
3. Set:
 - Hour (UP / DOWN)
 - Minutes (UP / DOWN or SET depending on version)
4. Press **ALARM** to confirm.

✓ A bell icon / “AL” indicator will appear when the alarm is active.

Turning Alarm ON / OFF

- Press **ALARM** briefly to toggle the alarm.
- The bell icon will appear or disappear.

⌘ Temperature Display

- Shown automatically in °C.
- If supported:
 - Hold **DOWN** to switch between °C and °F.

🕒 12 / 24 Hour Format

- Press **UP** or **MODE** to change format.
- On some versions, hold **SET** to switch.

🔄 Display Modes

Press **MODE** to cycle through:

- Time → Date → Temperature → Alarm

(Some models also support automatic cycling mode.)

🎮 Remote Control (if included)

- **MODE** – switch display modes
- **SET** – enter settings
- **▲ / ▼** – adjust values
- **ALARM** – alarm control
- **LIGHT** – brightness / backlight control

⚠ Power Supply

- Works with USB adapter (main power).
- Backup battery (if present) only preserves settings.
- The display does **NOT** run on battery alone.