

РАДИО ЧАСОВНИК С АЛАРМА ЕК-901-1

Настройване на часа

1. Свържете часовника към електрическата мрежа.
2. Натиснете и задръжте бутона **TIME** (или **CLOCK**, в зависимост от версията на модела).
3. Докато държите бутона:
 - Натиснете **VOL- / YEAR**, за да настроите часовете.
 - Натиснете **VOL+ / MONTH**, за да настроите минутите.
4. Освободете бутона **TIME/CLOCK**, за да запаметите настройката.

Настройване на алармата

1. Натиснете и задръжте бутона **AL SET**.
2. Използвайте **VOL- / YEAR**, за да зададете часа.
3. Използвайте **VOL+ / MONTH**, за да зададете минутите.
4. Освободете бутона **AL SET**, за да запаметите настройката.
5. Изберете желания режим на събуждане:
 - **AL1 BUZZER** – събуждане със звуков сигнал.
 - **AL2 RADIO** – събуждане с радио.

Слушане на радио

1. Натиснете бутона **UKW RADIO**, за да включите FM радиото.
2. Настройте желаната радиостанция с помощта на копчето **TUNING**.
3. Регулирайте силата на звука с бутоните **VOL-** и **VOL+**.
4. За изключване натиснете бутона **ON/OFF**.

Събуждане с радио

1. Включете радиото.
2. Изберете желаната FM радиостанция.
3. Настройте желаната сила на звука.
4. Активирайте режима **RADIO** за алармата.
5. В задания час радиото ще се включи автоматично.

Събуждане със звуков сигнал

Изберете режим **BUZZER**. В задания час часовникът ще ви събуди със звуков сигнал.

Функция **SNOOZE / SLEEP**

- Когато алармата звъни, натиснете бутона **SNOOZE/SLEEP**, за да отложите алармата с около **9 минути**.
- Докато слушате радио, натискайте бутона **SNOOZE/SLEEP**, за да зададете време за автоматично изключване на радиото (**Sleep Timer**).

Избор на 12/24-часов формат

Натиснете бутона **12/24H**, за да превключите между **12-часов** и **24-часов** формат на показване на часа.

Резервна батерия

Часовникът използва **3 V резервна батерия** (обикновено **CR2032**), която запазва настройките на часа и алармата при прекъсване на електрозахранването. Дисплеят и радиото не работят само на батерия.

Разположение на бутоните

- **VOL-** / **YEAR** – Намаляване на звука / Настройване на часа.
- **VOL+** / **MONTH** – Увеличаване на звука / Настройване на минутите.
- **ON/OFF** – Включване и изключване.
- **AL SET** – Настройване на алармата.
- **UKW RADIO** – Включване на FM радио.
- **TUNING** – Настройване на радиостанциите.
- **SNOOZE/SLEEP** – Отлагане на алармата и настройване на автоматично изключване.
- **12/24H** – Избор между 12- и 24-часов формат.

EK-902-1 Alarm Clock Radio

Setting the Time

1. Connect the clock radio to the AC power supply.
2. Press and hold the **TIME** button (or **CLOCK**, depending on the version).
3. While holding the button:
 - Press **VOL-** / **YEAR** to adjust the hour.
 - Press **VOL+** / **MONTH** to adjust the minutes.
4. Release the **TIME/CLOCK** button to save the current time.

Setting the Alarm

1. Press and hold the **AL SET** button.
2. Use **VOL-** / **YEAR** to set the hour.
3. Use **VOL+** / **MONTH** to set the minutes.
4. Release **AL SET** to save the alarm time.
5. Select the desired alarm mode:
 - **AL1 BUZZER** – Wake up with the buzzer.
 - **AL2 RADIO** – Wake up with the radio.

Listening to the Radio

1. Press the **UKW RADIO** button to turn on the FM radio.
2. Rotate the **TUNING** control to select the desired station.
3. Adjust the volume using the **VOL-** and **VOL+** buttons.
4. Press **ON/OFF** to switch the radio off.

Wake to Radio

1. Turn on the radio and tune to your preferred FM station.
2. Adjust the desired volume.
3. Set the alarm to **RADIO** mode.
4. The radio will automatically turn on at the preset alarm time.

Wake to Buzzer

Select **BUZZER** as the alarm mode. At the preset alarm time, the built-in buzzer will sound.

Snooze / Sleep

- Press **SNOOZE/SLEEP** when the alarm sounds to delay it for approximately **9 minutes**.
- While listening to the radio, press **SNOOZE/SLEEP** repeatedly to set the **Sleep Timer**, allowing the radio to turn off automatically after the selected time.

12/24-Hour Display

Press the **12/24H** button to switch between **12-hour** and **24-hour** time display formats.

Battery Backup

The **3 V backup battery** (typically **CR2032**) preserves the clock and alarm settings during a power failure. The display and radio do not operate on battery power alone.

Controls Overview

- **VOL-** / **YEAR** – Volume down / Time adjustment
- **VOL+** / **MONTH** – Volume up / Time adjustment
- **ON/OFF** – Power On/Off
- **AL SET** – Alarm setting
- **UKW RADIO** – FM Radio
- **TUNING** – Radio station tuning
- **SNOOZE/SLEEP** – Snooze and Sleep Timer
- **12/24H** – 12/24-hour display selection